

DWS – SERIES, DW-PRV – SERIES


Parts List

Description	Dwg Ref #	Part Numbers					
		DWS-75, -100, -125	DWS-150	DWS-200	DWPRV-75, -100, -125	DWPRV-150	DWPRV-200
Cover Assembly	2-11	4326	4419	4421	-	-	-
Cover	2 & 3	6615	6616	6617	6615	6616	6617
O-Ring	3 Only	4236	418	418	4236	418	418
Stem, Flow Adjustment	4	4320	970	970	4320	970	970
Stem For 75-125	4	5724	-	-	5724	-	-
Cross Handle	5	-	408	408	-	408	408
Nut, Cross Handle	6	-	409	409	-	409	409
Solenoid & Armature Assy	7	4333	4333	4333	4333	4333	4333
O-Ring Solenoid	8	476	476	476	476	476	476
Block Assembly	9	-	-	-	8266	8266	8266
Stem, Manual Bypass	10	-	-	-	8798	8798	8798
Bleed Petcock	11	738	738	738	738	738	738
Diaphragm Disc Assembly	13-18	4325	4418	4420	4325	4418	4420
Pin Bearing	13 Only	4319	4286	4286	4319	4286	4286
Upper Diaphragm Washer	14	4312	4473	4473	4312	4473	4473
Diaphragm	15	4318	4289	4393	4318	4289	4393
Disc Retainer	16	4311	4298	4397	4311	4298	4397
Disc, Rubber Seat	17	4314	4297	4396	4314	4297	4396
Disc Guide	18	4309	4296	4395	4309	4296	4395
Body Assembly 1-1/2" – 2"	19	-	4422	4423		4422	4423
Body Assembly ¾"	19	4344	-	-	4344	-	-
Body Assembly 1"	19	4345	-	-	4345	-	-
Body Assembly 1-1/4"	19	4346	-	-	4346	-	-
Cover Spring	20	407	4392	311	407	4392	311
Pin, Metering	21	402	322	290	402	322	290
Pin, Spring	22	303	303	303	303	303	303
Spacer, Ctr Guide Tube	23	-	4400	4400	-	4400	4400
O-Ring, Body	24	4404	4404	4404	4404	4404	4404
Cover Bolt	25	1198-45	1198-45	1198-55	1198-45	1198-45	1198-55
Regulator Assy (No Solenoid)	26	-	-	-	8799	8799	8799
Adjustment Screw	27	-	-	-	1198-56	1198-56	1198-56
Nut Hex 8-32NC	28	-	-	-	1118-06	1118-06	1118-06
Pressure Tap	29	-	-	-	7980	7980	7980
Valve Repair Kit	3,15,16,17,21	8371	8372	8373	8371	8372	8373
Valve Repair Kit	3,13,15,16,17,21	8377	8378	8379	8377	8378	8379


12/00
F-2402 Parts

2803 Barranca Parkway, Irvine, CA 92606
(949) 559-6000 Fax (949) 559-6088
www.GriswoldControls.com





DWPRV-75, 100, 125, 150, 200



12/00
F-2402 Parts